

DOCKET NO.: UPNA-0034/P2925
Application No.: 10/526,941

PATENT

IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

In re Application of:
Arjun G. Yodh et al.

Confirmation No.: **7568**

Application No.: **10/526,941**

Group Art Unit: **1793**

Filing Date: **September 8, 2005**

Examiner: **Brittany M. Martinez**

For: **Carbon Nanotubes: High Solids Dispersions and Nematic Gels Thereof**

Commissioner for Patents
P.O. Box 1450
Alexandria, VA 22313-1450

DECLARATION PURSUANT TO 37 C.F.R. § 1.131

I, Mohammad F. Islam, hereby declare that:

1. I am an inventor of the invention described and claimed in U.S. Patent Application Number 10/526,941 (hereinafter referred to as "the 941 application"), filed September 8, 2005, in the United States Patent and Trademark Office.
2. I am aware that the pending claims of the 941 application have been rejected as being unpatentable over U.S. Patent Application Pub. No. 2003/0133865 ("Smalley"). It has been explained to me that Smalley was filed on July 2, 2002, but that it claims priority from four U.S. provisional applications (collectively referred to as "the Smalley provisionals"):
 - Serial No. 60/303,469, filed July 6, 2001;
 - Serial No. 60/303,470, filed July 6, 2001;
 - Serial No. 60/337,561, filed November 8, 2001; and
 - Serial No. 60/337,951, filed December 7, 2001.
3. It has been explained to me that none of the Smalley provisionals disclose the use of at least one surfactant comprising an aromatic group.

4. In accordance with CFR § 1.131, as an inventor of the subject matter of the pending claims, and without conceding the propriety of the rejections of the pending claims, I hereby declare that I invented the subject matter with the inclusion of at least one surfactant comprising an aromatic group prior to July 2, 2002. I further hereby declare that I worked diligently from a date prior to July 2, 2002, to the date of constructive reduction to practice, September 10, 2002, the priority date of the 941 application, in order to prepare the 941 application and patent the invention.

5. In support of the instant declaration, a copy of relevant pages of a laboratory notebook prepared during the development of the claimed invention is attached hereto (Attachment B), which was created prior to July 2, 2002. The date range is from May 22, 2002 through July 20, 2002, which provides evidence of conception of the invention prior to the effective date of the Smalley reference and evidence of due diligence from prior to said date to the filing date of the provisional application, September 10, 2002.

6. I hereby declare that all statements made herein of my own knowledge are true and that all statements made on information or belief are believed to be true; and further, that these statements were made with the knowledge that willful false statements and the like are punishable by fine or by imprisonment, or both, under § 1001 of Title 18 of the United States Code, and that such willful statements may jeopardize the validity of the application, any patent issuing thereupon, or any patent to which this verified statement is directed.

Date: 01/20/2010

Signature: _____

M. F. Islam

Mohammad F. Islam

Exhibit A

Mohammad F. Islam

Chemical Engineering and Material Science and Engineering
Carnegie Mellon University
500 Forbes Avenue
Pittsburgh, PA 15213-3890

412.268.0593
FAX: 412.268.7596
mohammad@andrew.cmu.edu

EDUCATION

2000 Ph.D. Physics, Lehigh University, Bethlehem, PA 18015
1996 M.S. Physics, Lehigh University, Bethlehem, PA 18015
1994 B.S. Physics,

WORK EXPERIENCE

2005-Present Associate Professor, Chemical Engineering and Materials Science and Engineering
Carnegie Mellon University, Pittsburgh, PA 15213

2002-2005 Postdoctoral Fellow, Department of Physics and Astronomy
University of Pennsylvania, Philadelphia, PA

HONORS AND AWARDS

2007 Alfred P. Sloan Research Fellow
2007 National Science Foundation Career Award
2006 American Chemical Society PRF Award
1999 Sigma Xi
1997 Hoechst Celanese Award for Excellence in Polymer Science

CURRENT RESEARCH INTERESTS

Novel Self-Assembly and Phase Transformations in Single- and Multi-Component Systems: Formation of diverse structures as well as phase transformations in multi-component systems using temperature sensitive colloidal particles.

Utilizing Nanomaterials to Investigate Cellular Functions: Developing novel nanomaterial based vectors and investigating changes in cellular functions due to internalization of these vectors.

Carbon Nanotube Based Porous Materials for Energy Applications: Created ultra-light, highly porous materials with carbon nanotubes; Investigating use as electrodes and support for catalyst particles.

Dependence of Cell Functions on Substrate Properties: Developed polymeric hydrogels with tunable local stiffness and organization; Using materials to probe dependence of cellular functions on substrate stiffness and spatial organization.

Exhibit B

05/22/02

Make 2 samples of 1% Hipco + 10X NaDDBS in water
 each sample weighs 3g

add Hipco ~~0.03g~~

0.0321g

0.0324g

Make

~~add~~ NaDDBS

2.002g

stock

Total

10.03

} 19.96%Add

Hipco

0.0321g

0.0324g

NaDDBS

1.5221g

1.5103g

water

1.4653g1.4762g

Sample # 3

Hipco

0.0314g


NaDDBS

1.501g

water

1.480g

Dioxy Cholate



NT Project:

1. Scheme to separate & stabilize CNT without damaging it.

Tip Sonication (low f, high power) ~~Both~~ Bath Sonication (high f)

- Advantage over pyrene functionalized CNT
(damages CNT & ~~etc~~ destroys electronic property)

- Comment on Surfactant type for longer & better stability & separation

* Benzene & charge Surfactant best (NaDDBS)

(Literature is mostly on SDS)
(one paper ODA)

2. Fractionate CNT using either HPLC, SEC
or GPC

↑
Can use
this

↑
we use this

One paper on using GPC but do not elaborate
or show careful results. (Duesberg's group)

- Can use this technique for other Rod
shaped ~~or~~ particles.


3. Characterization:

Use mainly LS \leftarrow large statistics

Cross check for a few positions w/
AFM

4. Impact: stable, single CNT dispersions


Assembly, Controlled deposition ...
Ropes




05/19/02

Bill Degradó


~~the~~ more surfactants to try:



Phenyl alanine
(F)
Phe



Tyrosine



Tryptophan(W)
[Trp]

or Trimer of F (F3)

Also try Chaps & PEG

chiral proteins

Bill Degradó

JMB 2001

Butyl group, OH, benzene, amide group

Can we make chiral molecules to wrap around?

Use Hydrogen bonding.

06/18/02

Current Status of NT dispersion & characterization:

1% NT in NaDDBS

Bath sonic
dispersion

tipsonic
dispersion

electrophoresis
through
0.5%
Agarose
gel

Run through
Sephacrose 2B

AFM of
sample as is

electrophoresis
through 0.5%
Agarose
gel

AFM of
sample as is

cut gel
into
small
segments

sample
comes through
the gel.

↑
Unsuccessful;
sample does
not stick
to surface

↑
most did not
go through;
seems tipsonic
a good technique
to disperse HtpCo

↑
unsuccessful;
sample does
not stick
to surface

some of the
solution gets
trapped into

↑
modify surface

↑
Abandon this
method

ultra melt
centrifuge
gel at
through
filter

most
HtpCo
sticks
in
filter

saline

polylysine

Similar
as poly-L-
check

↑
successful;

They are
presumably
amorphous

↑
surface quality
& see if NT
sticks to the
surface

↑
HtpCo sticks to
surface after
dipping into soln
of HtpCo

Carbon,
bulky ball
etc
collect -
sample in
multiple
vials.

↑
next step
check the surface
quality & see
how NT looks like

Try this
approach
more

next step

look at a few
of them to see
how good is the
separation

07/01/2002

50 μ l
of sample
placed
on chip

wait for
5 min & then
shaken off

MI 10-4.000

Silane treated 10^{-4} H₂Co 5 μ m Scan in NaDB

(Too much surf)

MI 10-6.001

" " 10^{-6} "
(Too much surfactant)

MI 10-6.002

diff area, same chip

→ 10-4.003

10^{-4} chip rinsed in H₂O ~2 min

10-4.004

diff area, same chip

10-4.005

10^{-4} prepared by dunking in soln &
then rinsing with water, dried
with canned air

07/08/2002

Prepare 4g of 0.01% NT in NaDDBS from 1% NT in NaDDBS

1% NT soln

~~0.04g~~

0.0444g

} 0.01%

water

4.4434g

07/08/02

AFM on NaDBS stabilized ITPCO

ddb510-4.000

zoomed on the surface, leave it on
for 10 min, spin it at 3000 rpm
then add 2ml of water as the
sample is spinning.

→ no feature

ddb510-4.001

same sample - diff location

ddb510-4.002

dipped in soln, ~~then~~ for
5 min, then gently rinse
it in a water bath
- lots of NT

ddb510-4.003

zoomed in some where
in the previous ~~so~~ picture

.004

different place on sample (SP)

.005

Zoom in of .004 (SP)

.006

new location (on (SP)

ddb5/0-4.007

12th cut of gel ~~ph~~
phoresis sample

conc $\sim 10^{-4}$ NT in NaODS

I dipped the chip
in soln & then dried
& then rinsed in
water.

07/11/02

what I need to do:

conc

SDS

Tx100

NaDDBS

Prepare 1% → dilute to 0.01%

↑
Sonicate

↑
do not sonicate;
just dilution

Prepare 0.01% sample

✓✓

✓

↑
sonicate

I want to make 10% HiPCO soln,

9.96%

→ HiPCO 0.2000g

Add Rest 20% NaDDBS to get 2.0099

→ Final wt 2.0161g

07/12/02

Make 20 wt% TX-100 stock soln (50 grams)

TX-100 add 10 g

10.0061 g

Rest add water till 50 g

Total 50.00274 g

Make 499 1% ~~TX-100~~ NT soln w/ TX-100 (10%)

NT = 0.0397 g

TX-100 (20 wt%) = 2.0085 g

water = 1.9913

~ 1%

(0.984)

Also make 10^{-4} soln from 10^{-2} soln for AFM

SDS NT

1% soln = 0.0458 g

add water till = 4.604 g

~ 1×10^{-4}
(6.99×10^{-5})

NaDBS NT

1% soln = 0.0405 g

add water till = 4.0114 g

~ 1×10^{-4}

07/18/02

NT samples I have been looking at:

<u>A</u>	<u>A1</u>	<u>E1</u>
NaDDBS coated	Same	1% NaDDBS NT
NT	as A	Spun at 6000 rpm
10^{-4} dipped, rinsed	but <u>not</u> baked	while I pipetted
Baked	<u>2 μm scan</u>	on NT <u>saln</u>
ddbs dep. 0.000 \leftarrow 5 μ m	naddbsa.026	the Naddbsel.000
{ ddbs 10-4.040 }	- .037	- .004
- .051		before rigorous rinsing
<u>4 μm scan</u>	ddbs 10-4.021	After rinsing { naddbsel.008
	\downarrow	- .015
	5 μ m scan	
	.026	
	discard	
	<u>double tip</u>	
		Same baked
		naddbsel.040
		<u>bad</u>

<u>B2 NaDDBS NT</u>	<u>E</u>	<u>B</u>
1% 4000 rpm	NaDDBS 1%	NaDDBS NT
NaDDBS soln dropped	(Sample 1 month old)	1%
as chip was	Spins deposited	6000 rpm
spinning	naddbsel.000 \leftarrow before clean	Spin deposited
naddbsb2.000	.001 \leftarrow after clean	<u>2 μm</u>
- .002	- .007 conc. <u>NT</u>	{ Naddbsb.000 }
naddbsb2.003 \leftarrow After cleaning		- .001
		Image confusion
Baked	Baked	Baked
naddbsb2.040	overlapping	
- .042	Naddbsel.040	
same way prepared sample	- .042	
overlapping conc. NT		

280% 70/307

158/307 ~ 60%

212/307 ~ 73%

C
10⁻⁴ from 10⁻² dipped

Naddbs $\begin{matrix} .000 \\ .001 \end{matrix}$ } before baking

Naddbs $\begin{matrix} .040 \\ .048 \end{matrix}$ } after baking

no tube

F
10⁻⁴ from 10⁻² Sample (1) dipped

After baking

Naddbs $\begin{matrix} f.040 \\ .041 \end{matrix}$ } no tube

cut 12 new

12-2

ddbs 12 n. 000 } Long
 .008 } tubes

ddbs 12-2.000 } notubes

12th cut New-2

4th cut New1

20th cut

27th cut

ddbs 4N1,000

↓
.009

Found single
tubes

C2

dirty notube

10^{-4} from 10^{-2}
dipped, rinsed
& baked

C3

10^{-4} from 10^{-2} dipped, rinsed
baked

a lot of tubes

F2

10^{-4} from 10^{-2}
(sample ①)

dipped, Rinsed
baked

Naddbs F2,000

↓
.009

G7

10^{-5} from 10^{-4}

dipped, rinsed
& baked

C4

10^{-4} from 10^{-2} dipped,
rinsed, baked

a lot of tubes but
chip is dirty.

H1

H2

Bare surface
silane

treated, rinsed
baked

not
rinsed
&
baked

07/20/02

Prepare high conc. of Laser Tuber

Take 20mg of 5×10^{-3} by wt tubes in a glass bottle
& slowly evaporate water to increase conc.

Empty bottle w/o cap = 13.9254 g

w/tube w/o cap 28.9236 g

\therefore tube wt = 15.002 g at 0.5% wt

slowly evaporate at 44°C for several days

After some solvent evaporation w/tube w/o cap = 17.4744

\therefore tube soln wt = 3.549

New conc -

New conc = 2.113×10^{-2} by wt $\approx 2.113\%$ by wt

Prepare 0.1% NaDDBS-NT soln to sonicate 07/24/02

1% NaDDBS-NT = 0.4038g }
Add water till = 4.0127g } $\approx 0.1\%$

Prepare 0.1% SDS-NT soln

1% SDS-NT = 0.4009g }
Add water till = 4.0193g }